



Instructions - Propane Patio Heater

WARNINGS: DO NOT use in an explosive atmosphere. Keep heater away from areas where flammable liquids or vapors are stored or used.

1. **TURN OFF** LP tank when the heater is not in use.
2. **DO NOT** alter unit in any manner or bypass safety valve.
3. **DO NOT** operate heater without the reflector.
4. **ALWAYS** place heater on a hard and level surface.
5. **DO NOT** use if wind velocity is greater than 10 mph because of flame-out possibility.
6. **ALWAYS** Wait 5 min. to relight a hot patio heater.
7. **Make sure Heater top is 36 in min under any surface & 36 in from the side of any wall.**

Before Turning the Gas Supply "ON":

1. **INSPECT** hose assembly for excessive wear or cuts.
2. **REPLACE** a leaking hose prior to use with a hose that meets manufacturer specifications.
3. **CHECK** that surrounding area is free of combustible materials.

To Light:

1. Check that regulator connections are correct and tight.
2. Turn tank valve in a counter clockwise direction. Check for leaks by applying soapy water to connections (Teflon tape provides a leakproof fit.)
3. Turn control knob counter clockwise to the pilot position.
4. Depress and hold in control knob to begin pilot gas flow: Hold in control knob for **3 minutes** on new installations or tank changes to purge air from lines, or 10 seconds for regular relight. While depressing knob, depress ignitor button, which will snap indicating it has produced a spark, which should light the pilot. If not, depress control again and depress the auto pilot ignitor



(White heaters) until lit or match light. Pilot is located behind match hole cover. Rotate disc upward from hole for access.

5. Once pilot is lit, continue to hold in control knob for 30 seconds or until pilot remains lit after knob is released.
6. Turn burner to "**ON**" position (all the way counter clockwise) and then reduce to desired heat range.

Relighting:

1. Turn control knob to off position.
2. Wait 5 minutes before attempting to relight pilot.
3. Repeat steps beginning with step 4 above.

Shut-Down Instructions:

1. Turn control knob clockwise to "**OFF**" position.
2. Turn tank valve clockwise to "**OFF**" when heater is not in use.